



The photos above show the underside of the Stop. A 2mm setback in the V Channel Insert allows material of a smaller gauge to slide under the Stop and not slip up when the wire is cut. The opposite side of the V Channel does not have a setback and is flush with the face. Slide the Stop off the Jig and rotate it so the knurled knob is on the left. Slide the Stop back on the Jig and screw down the knurled knob to set the length of material to be cut. For smooth movement of the Stop, push from the center.

The photo below shows the end view of the jig with the Saw Guide removed. Insert the Thumbscrew through the hole in the Saw Guide and screw it into the Jig lining up the Stabilizing Plug in the adjacent hole.

To saw from the opposite direction unscrew the Thumbscrew and insert it into the Saw Guide from the opposite end. Rotate the Saw Guide 180° with the V Channel on top and screw the Thumbscrew into the Jig.

Left handed and right handed positions of the Saw Guide.
Remove the Saw Guide to flush cut wire.

For hands free use: Screw through the beveled hole in the upper left of the Jig and into your bench. Or remove one of the screws attaching the Aluminum Surface to your Jayne Redman® Rotational Bench Pin. Use it to screw directly through both the beveled hole in the upper left of the Jig and the Aluminum Surface into the Rotational Base. Place the wire or tube into the V Channel and push it firmly with one hand against the Stop while flush cutting or sawing with the other hand.



Remove the saw guide to flush cut wire.



Sawing left handed. Jig mounted on Jayne Redman® Rotational Bench Pin for hands free use.



Sawing right handed.